

Copyright Statement

© Datapath Ltd., England, 2014

Datapath Limited claims copyright on this documentation. No part of this documentation may be reproduced, released, disclosed, stored in any electronic format, or used in whole or in part for any purpose other than stated herein without the express permission of Datapath Limited.

Whilst every effort is made to ensure that the information contained in this documentation is correct, Datapath Limited make no representations or warranties with respect to the contents thereof, and do not accept liability for any errors or omissions.

Datapath reserves the right to change specification without prior notice and cannot assume responsibility for the use made of the information supplied.

Datapath Limited acknowledges all registered trademarks used within this documentation.

20		Toxic or Hazardous Substances and Elements 有毒有害物质或元素					
RoHS		铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
Contents	实装基板	×	○	○	○	○	○

备注：(○或×) 的表示意思
○：表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。
×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。

UK Headquarters

Datapath Ltd.,
Bemrose House, Bemrose Park,
Wayzgoose Drive,
Derby,
DE21 6XQ,
United Kingdom

Tel: +44 (0) 1332 294441

Fax: +44 (0) 1332 290667

US Office

Datapath North America
2490 General Armistead Avenue
Suite 102
Norristown, PA 19403
USA

Tel: +1 484 679 1553

Email: sales@datapath.co.uk

Web: www.datapath.co.uk

VisionSD4+1S

Four Channel Video and One Channel RGB/
DVI/ HD Capture Card




DATA PATH

PACKING LIST

Your packing box should contain the following items:

The VisionSD4+1S video capture card.

1 x SD4-Cable.


1 x DVI-VGA, 1 x DVI/Component and 1 x DVI/HDMI Adapters.

Installation CD-ROM.

(For latest drivers go to www.datapath.co.uk).

NOTE:

All plug-in cards are static sensitive and are packed in antistatic materials. Please keep the card in its packaging until you are ready to install.



HARDWARE INSTALLATION

You are likely to need a flat blade and a Phillips head screwdriver for the installation of the capture card; installing the card is a simple process, follow the steps below to be up and running in a few minutes.

Power down the PC (including peripherals), switch off at the mains and disconnect all the cables connected to the computer, noting the positions for accurate reconnection. Remove the PC cover.

Locate a vacant PCI Express (x4 or above) slot on the motherboard and remove the backing plate (retain all screws).

If in doubt consult your motherboard documentation to correctly identify a PCI Express) slot. If the card is forced into a 32 or 64 bit PCI or PCI-X slot it will be irreparably damaged when the system is powered up and the warranty will be void.

Remove the card from its packaging and secure it firmly into the empty PCIe slot.

Extreme care should be taken when securing the card into the slot as some motherboards may have components that impede the siting of the card.

Screw the card bracket to the back panel of the PC and replace the cover. Re-connect all cables to the PC.

Connect the input cables. Power up the PC and commence the software installation.

Reconnect all cables to the PC then connect the cable distributing the RGB/ DVI/video signals to the connectors on the VisionSD4+1S card located on the back panel.

SOFTWARE INSTALLATION

Insert the Datapath CD into your CD drive, the CD will autorun and display the following dialogue. If the CD drive fails to autorun browse the CD and locate and double click the **setup.exe** file.

Click on **Install Software...** and follow the installation Wizard instructions as prompted.



We suggest that you regularly visit the Datapath web site for information on updated drivers. (www.datapath.co.uk)

It is strongly recommended that you read the detailed help instructions on completion of the installation. Each help topic may be printed for ease of use.